



WindChaser Products: Developers of Fans, Heaters,  
Air-Treatment Products, Portable Air-Conditioners and  
Portable Ice Makers

an **EefaCo.** Store  
1-800-667-8721




©2005 WindChaser Products, Inc.

PLEASE READ BEFORE USE AND SAVE

Remote Control Horizontal / Vertical  
**WindColumn**™  
with Ion Generator

INSTRUCTION MANUAL



## CONTENTS

Remote Control Horizontal / Vertical

# WindColumn™

with Ion Generator

MODEL WCH3iRO

Before Initial Use	2
For Your Safety	3
Parts	4
Preparation	5
Operating Instructions	6
Cleaning and Storage	7
Limited Warranty	8

an *Eefa*Co. Store  
1-800-667-8721



## BEFORE INITIAL USE

Read this Entire Instruction Manual Before Use.

Attach your purchase receipt here

**PLEASE KEEP YOUR RECEIPT.**

**YOUR RECEIPT IS YOUR PROOF OF  
PURCHASE AND IS NECESSARY FOR  
WARRANTY SERVICE**

**For your reference:**

Serial No. \_\_\_\_\_ Date of Purchase \_\_\_\_\_

Name and Address of Dealer \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

an *Eefa*Co. Store  
1-800-667-8721

## FOR YOUR SAFETY

### IMPORTANT INSTRUCTIONS

Read and save these important safety instructions before using this fan. When using electrical appliances, basic safety precautions should always be followed including the following:


- 1) Use this fan only as described in this manual. Other uses not recommended may cause fire or electric shock.
- 2) This product is intended for household use ONLY and not for commercial, industrial or outside use.
- 3) To protect against electrical shock, do not place fan in window, immerse unit, plug or cord in water, or spray with liquids.
- 4) When touching the unit, be sure hands are dry to prevent electric shock.
- 5) Do not use outdoors.
- 6) Do not run the power cord under carpets, and do not cover the unit with a rug or any type of cloth material. Arrange the cord in such that it will not be tripped over.
- 7) Close supervision is necessary when any appliance is used near children.
- 8) Unplug the fan from the outlet when not in use, when moving fan from one location to another and before cleaning.
- 9) Do not operate the fan in the presence of explosive and/or flammable fumes.
- 10) Do not place the fan or any parts near an open flame, cooking or other heating appliance.
- 11) Do not operate the fan with a damaged cord, plug, after a malfunction or if dropped or damaged in any manner.
- 12) Avoid contact with moving fan parts.
- 13) To disconnect, grip the plug and pull it from the wall outlet. Never yank the cord.
- 14) The use of attachments is not recommended and may cause hazards.
- 15) Always use on a dry level surface.
- 16) Do not operate if the fan housing is removed or damaged.
- 17) THIS PRODUCT IS EQUIPPED WITH A POLARIZED A.C. (Alternating Current) PLUG - a plug having one blade wider than the other. This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact an electrician to replace the obsolete outlet. DO NOT DEFEAT THE SAFETY PURPOSE OF THIS POLARIZED PLUG.

**WARNING:** The unit has an ion generator inside. **DO NOT ATTEMPT TO OPEN THE HOUSING.** There is the presence of high voltage and risk of electric shock. No user servicable parts available.

**WARNING:** To reduce the risk of fire or electrical shock, **DO NOT USE THIS FAN WITH ANY SOLID STATE SPEED CONTROL DEVICE.**

### SAVE THESE INSTRUCTIONS

## PARTS




an *EefaCo.* Store  
1-800-667-8721

## PREPARATION



### FAN

1. Place the unit on a dry, level surface.
2. Plug the power cord into a standard 120VAC wall outlet.

### REMOTE CONTROL



1. Remove the cover from the back of the remote control.



2. Insert two AAA dry-cell batteries (included).

3. Do not use rechargeable batteries because they differ from standard dry cell batteries in shape, dimension and performance.
4. Be sure to replace the batteries with two new batteries of the same type.
5. Remove the batteries if the fan is not going to be used for an extended period of time.
6. Always point the remote control toward the unit when operating with the remote control.
7. All function keys are enabled after pressing the ON/OFF button.




Fig.1





Fig.2

8. Make sure nothing is obstructing the remote control signal in front of the fan (Fig. 1)
9. The maximum distance the remote control can operate the fan from is 9.8ft (3m)(Fig. 2).

# OPERATING INSTRUCTIONS



## Function Indicator Lights

The unit can be operated by the Control Panel or the Remote Control. The unit will beep each time a button on the remote or control panel is pressed.

### 1. OSCILLATE (↔)

Press to turn the oscillation function ON or OFF.

### 2. TIMER (⌚)

Press the TIMER button until the desired Shut-Off time is shown on the timer indicator lights (2). The timer can be set for 1, 2, 4, 8 hours.

### 3. SPEED (⚙️)

Press to select between Low, Medium or High fan speeds. The speed selected will be indicated by the corresponding LED lights - Low (∼), Medium (≈) or High (≡).

### 4. WIND MODES (🌬️)

Natural (🌬️) and Sleep (Zz) Wind Modes both run under a pre-set rhythm. The only difference is that the fan speed will go a step down every 30 minutes in Sleep Mode.

an *Eefa*Co. Store  
1-800-667-8721

For example, the fan is running on HIGH speed while in SLEEP MODE:

HIGH (Natural Wind) for 30 min. - MED (Natural Wind) for 30 min. - then the fan will continuously run on LOW (Natural Wind).

In MEDIUM speed while in SLEEP MODE:  
MED (Natural Wind) for 30 min. - then the fan will continuously run on LOW (Natural Wind).

In LOW speed while in SLEEP MODE the fan will continuously run on LOW (Natural Wind)

NOTE: The timer can be used while running any of the Wind Modes.

The selected mode will be indicated by an LED light on the display.

#### 5. ION GENERATOR ( )

Press to turn ON or OFF the Ion Generator. The Ion light (3) will illuminate when the Ion Generator is on.

**NOTE: The ion generator produces negatively charged ions which remove airborne contaminants such as smog, pollen and dust. Ion Generator is capable of cleaning the air in a 21.22 ft<sup>2</sup>. (2m<sup>2</sup>) room.**

#### 6. POWER BUTTON ( )

Press to turn the unit ON or OFF.

## CLEANING AND STORAGE

1. Turn the unit OFF and unplug the unit before cleaning.
2. Use only a soft, damp cloth to clean the exterior. A can of compressed air and a vacuum cleaner can be used to clean the interior. Spray compressed air through the grills and then vacuum the dust that comes out.
3. Do not immerse the unit in water and never allow water to drip into the Motor Housing.
4. Do not use gasoline, paint thinner or other chemicals to clean the fan.
5. Store unit in it's original box and store in a cool, dry place.

**NOTE: If you experience a problem, please return the unit to the place of the original purchase or see your warranty. Do not attempt to open the motor housing yourself. Doing so may void your warranty and cause damage to the fan or personal injury.**

an *Eefa*Co. Store  
1-800-667-8721



## LIMITED WARRANTY

### One (1) Year Limited Warranty Terms and Conditions

This warranty applies to repair or replacement if a product is found to be defective in material or workmanship. This warranty does not apply to any damage resulting from commercial, abusive and/or unreasonable use or supplemental damage. Defects as a result of normal wear and tear will not be considered manufacturing defects under this warranty.

Read the instruction manual before attempting to use this product.

WindChaser Products, Inc. is not liable for incidental or consequential damages of any nature. Any implied warranty of merchantability or fitness for a particular purpose on this product is limited in duration to the duration of this warranty. Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you also may have other rights which vary from state to state. This warranty applies only to the original purchaser of this product.

WindChaser Products, Inc. will repair or replace this product if it is found to be defective in material and/or workmanship. Defective product should be returned to the place of purchase in accordance with store policy. Thereafter, while within the warranty period, any defective product should be returned to WindChaser Products, Inc.. This warranty does not cover damage resulting from unauthorized attempts to repair or from any use not in accordance with its manual.

an *Eefa*Co. Store  
1-800-667-8721